

MATS-2010M**Soft Magnetic Material Dynamic Hysteresisgraph System****Model MATS-2010M**

Automatic measurement on dynamic hysteresis loop of soft magnetic (silicon steel) material under 50Hz, 60Hz, 400Hz and 1kHz, accurate measurement on dynamic magnetic characteristic parameters such as amplitude permeability μ_a , loss angle δ , total losses P_s , remanence B_r and coercive force H_c .

Windows measurement software applied simply. The product conforms to China National Standards GB / T3655 - 92, GB / T13789 - 92 and international standard IEC60404 - 6.

Analog source (bridge), frequency meter, ammeter, voltmeter and wattmeter are replaced through computer control and A/D sampling, entire testing process automatically completed.

General Features**Software Features****Software Screen****Technical Data****Standard Package**

- Testing sample varieties: hot rolling, cold rolling silicon steel materials, permalloy, amorphous and nm crystal.

- Testing sample shapes: ribbon and chip open samples, annular, E and U closing samples.

- Open circuit samples adopt epstein frames to form closed magnetic circuit, can also select permeameter. Closing sample can be put under direct winding measurement, finished transformer can be also put under direct measurement.

- Sample(iron core), magnetizing coil (N1) and measuring coil (N2) form a no-load transformer.

- On-inductive resistance connected on magnetizing coil loop to determine magnetizing current and magnetic field intensity through the measurement of pressure drop on non inductive resistance, magnetic field peak value can be locked through digital feedback, magnetic field lock precision 0.5%.

- Magnetic induction density obtained through digital integration of coil measuring voltage, magnetic induction peak value locked through digital feedback, magnetic induction lock precision 0.2%.

- Power source and sampling amplifier integrated into a casing with simple interface: one RS232 interface connected to the computer, two way voltage signal connected to A/D card.

- Adopt volammety and digital integration to measure dynamic hysteresis loop, can accurately measure dynamic magnetic characteristic parameters such as μ_a , δ , P_s , B_r and H_c , etc.

- Automatic and continuous measurement up to 255 testing points, the testing time of every testing point is about 30 seconds, fixed-frequency, fixed B_m or fixed H_m optional in multipoint test.

Copy Right 2001 YUXIANG Magnetic Materials Ind. Co.,Ltd. All Rights Reserved
Add :F/16, Jinyuan plaza, # 57 South Hubin.Rd, Xiamen, CHINA 361004
Tel : (86)592 2295387 (86)592 2217138 Fax: (86)592 2207122
Email : susana@aaamagnet.net